

# HATCH CATCH

DIP SW 1		1	2	3	4	5	6	7	8
DEMO SOUND	NO	Off							
	YES	On							
COIN : CREDIT	1 : 1			Off	Off	Off			
	1 : 2			On	Off	Off			
	2 : 3			Off	On	Off			
	1 : 3			On	On	Off			
	2 : 1			Off	Off	On			
	3 : 1			On	Off	On			
	4 : 1			Off	On	On			
	5 : 1			On	On	On			
DIFFICULTY	NORMAL						Off	Off	
	HARD						On	Off	
	HARDEST						Off	On	
	EASY						On	On	
START MODE	GAME MODE								Off
	TEST MODE								On